



Here are your stickers and instructions on how to put them on!

Important tips before starting

- If there is any RAIN-X, remove it from window using rubbing alcohol or decal will not stay on.
- Decals should only be applied to surfaces that are 60 degrees or higher for maximum tack.
- Make sure it is sunny out but perform install in the SHADE. High humidity is bad for drying. (Consider using a hairdryer).
- Due to unavoidable folding during shipping, FLATTEN OUT DECAL as best you can. If the sticker is bent it won't negatively affect the application.

Installation Steps

1. Clean vehicle surface/window well, remove all dirt.
2. Spray down windshield with a mixture of soap and water or BLUE Windex...Leave the surface wet (using your hands smear mixture around).
3. Hold decal so it faces you. (See pic #1)
4. Flip to opposite side of the sheet (See pic #2)
5. Slowly peel off the backing (solid sheet, not the see through). Throw out the backing.
6. Lightly mist (spray) the now exposed tacky side of the vinyl with soapy water/Windex and place TACKY SIDE (now wet) against the surface or outside of the window that you wish to place the sticker on (also wet). (See pic #4)
7. Line up the decal so that it is even on the surface (may require measuring). Wet application allows for some sliding of the decal into place. Make sure there are no wrinkles or bubbles and decal is flat.
8. Begin pushing out soapy water/Windex using a squeegee or a credit card, starting from the center of the decal out to the sides.



9. Allow ½ an hour to dry in DIRECT SUNLIGHT.
10. Slowly peel transfer tape away from the surface and decal (See pic #5). If any part of the decal wants to come up with the transfer tape, push it down firmly using the transfer tape and try peeling that portion up again (hairdryer may help make decal stay down).
11. If there are any wrinkles or bubbles left after transfer tape is removed, push by hand, or squeegee. If this does not work, prick the bubble with a pin and push the water/air out.

